

Print - Cut - SolProtect® ... done!

SolProtect® Application instructions

For the simple application of SolProtect®, get from your local specialist dealer the SolProtect®-Special sponge, or even better the practical GRIPS (sponge with clamping handle) and SOLBOX (working and storage box).

Fill about 2 cm SolProtect® liquid laminate into the SolBox.

Place the dry sponge in the liquid laminate, until it has saturated with a sufficient quantity of SolProtect®.

Wipe off the sponge at the edge of the box...

and apply SolProtect® quickly and evenly, not too thin onto the horizontally lying, dry inkjet prints.
On our website you will find a short video!

On a few difficult materials there may be wetting problems when applying SolProtect®. In this case, we recommend the special **SolProtect+** with enhanced wetting properties. If the problem still remains, wipe dry SolProtect® with absorbent paper and apply a new layer on it.

Check whether SolProtect® was applied on the entire surface everywhere.

The airflow of a fan can reduce the drying time significantly.

After a drying time of about 10-20 minutes (depending on room temperature)...

weed the stickers... done!

The sponge can be kept for the next application in the well sealed SolBox with a small amount of SolProtect®!

For latest information and video instruction see:
www.solprotect.com

